



ZOWEETEK

User Guide

ZW-BSP03



ROHS



Contents

1. Introduction	2
2. Battery	3
3. Getting Started	4
4. Cable Connection	4
5. Bluetooth Connection	5
6. NFC Connection	6
7. Microphone Usage	6
8. Charging And LED Indicator Light	7
9. Product Care	8
10. Contact Us	8

Please read the following safety warnings and precautions before using your device.

Specification

ZW-BSP03

Output Power: 8W

S/N: >75dB

Frequency Range: 60Hz-20KHz

Power Supply: Lithium battery or USB cable

Audio Source: iPhone, iPad, Smartphone, Notebook, MP3, MP4, etc

Function Spec: Bluetooth, Microphone, Line-in

Size: 5.7 x 1.8 x 2.2 inch

Rechargeable battery with charging option from USB cable

Operating range up to 33 ft

1. Introduction_____


Thank you for purchasing ZW-BSP03. This device can be easily connected with audio or video devices for your daily needs. The speaker supports both Bluetooth and Aux-in function.

2. Battery

The device is powered by a built-in rechargeable lithium battery. Please charge the battery at least 8 hours before your first use of device.

- If the device is not used for a long period of time, the battery may be out of power. Please charge it.
- Rechargeable battery is charged only under adult supervision.
- Do not attempt to open the rechargeable battery or battery pack.
- There are no serviceable parts inside.
- If the battery leaks, it may be damaged. Please contact us and don't charge it.
- Avoid storing the battery in extremely hot or cold environment. A device with a hot or cold battery may not work, even when the battery is fully charged.

3. Getting Started



4. Cable Connection



When playing music via AUX cable, "Previous", "Next" and "Play/Pause" may be not supported.

5. Bluetooth Connection ---


Pairing SoundPlus to your device (device should be within 33 ft of your speaker)

1. Activate speaker on ZW-BSP03 by pressing "ON/OFF" button.
2. When the LED flashes blue, the speaker is in pairing mode and can be searched.
3. Open your device Bluetooth function. Select "Search" or "Discover devices", then select "ZW-BSP03".
4. If requested, type the password or PIN 0000.
5. In case of unsuccessful pairing, please reset the speaker Bluetooth function and re-turn on your devices Bluetooth function.

Note:

1. Long press the "Play/Pause" button to restart speaker Bluetooth function.
2. When the bluetooth and Aux cable are both connected, the cable will get the priority.
3. When paired to computer via bluetooth, "Previous", "Next" and "Play/Pause" are not supported.
4. If you turn off your device Bluetooth function or turn off the speaker, but the speaker is remained on your devices bluetooth list, when you open your device Bluetooth function and re-turn on speaker, the bluetooth will be connected automatically.
5. When the distance between your device and this speaker is over speaker bluetooth receiving range, after 10 minutes, this speaker will disconnect with your devices and turn into pairing mode. If within 10 minutes your device is back, the speaker will connect this speaker automatically.

6. NFC Connection



NFC: Near Field Communication, is a set of standard for smartphone and this speaker to establish Bluetooth radio communication with each other by touching them together or bringing them into close proximity, usually no more than a few centimeters.

Please active the NFC function (subjects to device own setting) of your smartphone. Put your smartphone NFC sensor area close to speaker NFC logo, as above picture.

7. Microphone Usage


When a phone call comes in, you could talk through the microphone on speaker.

Tips: When you make a call from your mobile phone the call will (subject to phone settings) automatically transfer to your SoundPlus.

If you want to use its mic on your computer, you may need a extra audio adapter (Not include in package) for computer audio output port and mic port.

8. Charging and LED Indicator Light _____

Built-in lithium battery, can be charged through micro USB cable, see below picture:



The indicator light status display as below:

	LED Display	Light Indication
Blue Light	Flash slow	Ready to pair
	Stay solid	Paired
Red Light	Flash fast	Low battery
	Stay solid	Charging in process
	Turn off	After fully charged

Max charging voltage and current: 5V, 1A

Note:

1. When you use charger to charge the speaker, please ensure that the charger does not exceed the maximum voltage and current before charging. Otherwise it will damaged the battery.
2. When LED light flashes red or speaker makes a continous sound of "bi bi", the speaker battery is low power and it needs charging.

9. Product Care

Your device is designed to be heavy and durable. As an electronic device, it must be treated carefully. Putting unnecessary pressure on it or striking the device against other objects may cause damage.

- Do not drop, crush, bend or apply excessive force to the device.
- Clean the unit with a soft cloth or damp chamois leather. Never use solvents.
- The unit can only be opened by qualified person.
- This device contains magnets. Keep magnetic field sensitive products such as credit cards and video screen away from this device to avoid damage or malfunction.

Keep the speaker out of reach of children. The silica gel is easy to be swallowed by children. If swallowed, consult a physician immediately.

10. Contact Us

If you want to learn more about this speaker or you have other questions, please browse our official website or email us.

Our official website: www.zoweetek.cn

Email: support@zoweetek.com

